



## Hilti Tool Service

### Strojevi koji se ne servisiraju od 2016. godine

Udarni čekići	Prestanak servisa
TP 400	2010-12-31
TE 504	2014-12-31
TE 704	2014-12-31
TP 800	2007-12-31
TE 804	2012-12-31

Bušilice	
TE 1 (Gen 1)	2015-12-31
TM 8	2004-12-31
TE 10	2012-12-31
TE 10-A	2010-12-31
TE 10-S	2012-12-31
TE 12	1998-12-31
TE 12-S	2004-12-31
TE 14	2008-12-31
TE 17	1993-12-31
TE 22	2006-12-31
TE 22-P	2014-12-31
TE 24	2012-12-31

Dozatori	
BD 2000	2014-12-31
CB 100-P1	-
CB 200-P	-
CB 120-P1	-
CB 120-P2	-
ED 3500	2013-12-31
ED 3500-A	2013-12-31
K 300	1996-12-31
P 2000	2012-12-31
P 3000-D	2007-12-31
P 3000-F	-
P 3500 (F)	-
P 5000	2012-12-31
P 5000-HY	2012-12-31

Usisivači	
TDA VC30	2011-12-31
TDA VC40	2010-12-31
TDA VC60	2011-12-31
VCD 50	2015-12-31
VCU 40	2015-12-31
VCU 40-M	2015-12-31
WVC 40-M	2011-12-31

Dijamantno rezanje	
DC SE19	2013-12-31
WSU	2013-12-31
DD VP7	2015-12-31
DS KC62	2012-12-31
DS KC80	2012-12-31

Dijamantno bušenje	
DCM 1	2010-12-31
DCM 1.5	2010-12-31
DCM 2	2010-12-31

Direktno pričvršćivanje - plin	
GX 100-E*	2016-12-31
R4X12*	2016-12-31
X-GM 20*	2016-12-31

Direktno pričvršćivanje - barut	
DC58	2010-12-31
D66L	2011-12-31
DP4-I	2004-12-31
DX A70-R	2011-12-31
DX 200	2000-12-31
DX 650	2006-12-31
R4DW	1998-12-31
SX 335	2005-12-31
SX 339	2005-12-31
SX 345	2005-12-31
SX 346	2005-12-31
SY 905	2005-12-31
SY 910	2005-12-31
36M32	2006-12-31
36M62	2006-12-31
DXA70R-M	2011-12-31
MX 32	2011-12-31
MX 62	2011-12-31
MX 75	2011-12-31
X-AM 32	2011-12-31

Kombinirane bušilice	Prestanak servisa
TE 42/52	2006-12-31
TE 54	2011-12-31
TE 60 (1. gen)	1996-12-31
TE 70H	2012-12-31
TE 72	2005-12-31

Pile i brusilice	Prestanak servisa
WFE 150	2008-12-31
WSC 55	2008-12-31
WSC 155	2014-12-31
WSC 255	2014-12-31
WSC 265	2014-12-31
WSC 267-E	2015-12-31
WSJ 110-EB	2011-12-31
WSJ 110-ET	2011-12-31
WSR 900	2015-12-31
WSR 1000	2010-12-31
WSR 1200PE	2012-12-31
WSC 55-A*	2016-12-31
WSC 6.5-A*	2016-12-31
WSC 167*	2016-12-31
WSC 255-KE*	2016-12-31

Zavrtači	
SB 10	2006-12-31
SB 12	2006-12-31
SF 120-A	2008-12-31
SF 150-A	2012-12-31
SF 180-A	2014-12-31
TCD 12	2002-12-31
TCI 12	2013-12-31
UH 240-A	2015-12-31
SD 45	2011-12-31
SDT 25	2015-12-31
SR 16	2014-12-31
ST 18	2010-12-31
SU 25	2010-12-31
TAD 500	2013-12-31
TDR 1000	2003-12-31
TDR 1600	2003-12-31
TDR 1600	2003-12-31
TDR 3000	2003-12-31
TKD 3000	2002-12-31
TKD 5000	2002-12-31
TKS 1300	2004-12-31
TKT 1300	2003-12-31
TKT 1800	2003-12-31
TKT 2000	2003-12-31
TKT 2500	2003-12-31
TRH 1800	2004-12-31
UH 650	2014-12-31
SMI 55	2014-12-31

<b>Baterije</b>	
B 144	
B 18/2.6	
B 22/2.6 (Gen 1)	
B 24/2.0	
B 36/2.4 Li	
B 36/2.6	
B 36/3.3	
BP 686	
BP 10	
BP 12	
BP 40	
BP 60	
SBP 10	
SBP 12	
SFB 121	
SFB 125	
SFB 150	
SFB 180	
CU 10	2009-12-31
SFC 7/18	2012-12-31
SFC 7/18-H	2012-12-31

TE 74	2011-12-31
TE 75	2014-12-31
TE 92	2008-12-31
<b>Kutne brusilice</b>	
AG 100-S	2015-12-31
AG 125-S	2015-12-31
AG 125-SE	2015-12-31
DAG 100-S	2015-12-31
DAG 115-S	2014-12-31
DAG 450-D	2014-12-31
DC 125	2008-12-31
DC 500	2008-12-31
DC 125-S	2015-12-31
DC 180-S	2014-12-31
DC 700-S	2014-12-31
DC 230	2008-12-31
DC-EX	2015-12-31
WS 100	2008-12-31
WS 115	2008-12-31
WS 125	2008-12-31
HG 500 (L)	2008-12-31
WS 180	2008-12-31
WS 230	2008-12-31
AG 230-S*	2016-12-31
DC 230-S*	2016-12-31

SF 100-A*	2016-12-31
SF 151-A*	2016-12-31
SF 181-A*	2016-12-31
SF 4000-A*	2016-12-31
SFH 151-A*	2016-12-31
SFH 181-A*	2016-12-31
SD 2500*	2016-12-31
SF 4000*	2016-12-31

<b>Mjerna tehnika</b>	
FS 10	2011-12-31
PD 10	2005-12-31
PD 20	2008-12-31
PD 22	2009-12-31
PD 25	2008-12-31
PD 28	2011-12-31
PD 30	2012-12-31
PD 32	2012-12-31
PD 38	2015-12-31
PL 10	2005-12-31
PL 10 N	2008-12-31
PM 10	2009-12-31
PM 22	2011-12-31
PM 24	2011-12-31
PMA 30	2014-12-31
PMC 36	2015-12-31
PML 32	2012-12-31
PP 11	2014-12-31
PR 10	2006-12-31
PR 15	2007-12-31
PR 16	2011-12-31
PR 20	2014-12-31
PR 25	2015-12-31
PR 26	-
PR 50	2007-12-31
PR 60	2009-12-31
PRA 20	2014-12-31
PRA 30	2014-12-31
PRA 801	-
PS 20	2011-12-31
PA 350*	2016-12-31
PML 32-R*	2016-12-31
PMP 32*	2016-12-31
PMP 34*	2016-12-31
PMP 34-F*	2016-12-31
PR 25-IF*	2016-12-31
PR 28*	2016-12-31
PRA 22*	2016-12-31
PRA 25*	2016-12-31

## Posebna ponuda "STARO ZA NOVO"

### Zamjena stroja u tri koraka:

1. Donesite svoj stari Hilti stroj u najbliži Hilti center ili nazovite besplatni telefon 0800 94 42
2. Preuzet ćemo vaš stari stroj i u zamjenu za njega ponuditi ćemo vam dodatne pogodnosti pri kupnji novog, zamjenskog stroja
3. Vaš stari stroj ćemo ekološki zbrinuti umjesto vas

\* Stroj se prestaje servisirati 31.12.2016.